
CALIS CAS series

Original operating instructions




Table of contents

1	Foreword	4
2	Safety.....	4
2.1	Notes and symbols used.....	4
2.2	Personnel qualification.....	5
2.3	Intended use	5
2.4	Reasonably foreseeable misuse.	5
3	General description	6
4	Installation.....	6
4.1	Determine the minimum distance to the side walls.	6
4.2	Installation implementation.....	7
5	Operation	8
5.1	Identity tab	9
5.2	Firmware Update.tab	9
5.3	Specialist tab.....	10
5.4	Process data sub-tab.....	10
5.5	Identification sub-tab.....	10
5.6	Parameter sub-tab	11
5.7	Configuration of the measurement - distance for overfill warning.....	11
5.8	Adjustment of the sensor (fill level to distance) - Container Teach in	11
5.9	Pin 4 Configuration	12
5.10	Brightness of the LED	13
5.11	Observation sub-tab	13
5.12	Diagnosis sub-tab.	13
5.13	Register Events.....	14
6	Maintenance	14
7	Dismantling	14
8	Disposal.	15
9	Technical data.....	15
9.1	Dimensioned drawing.	16
9.2	Pin assignment.....	16

10	Manual updates	16
11	Legal notice	16
12	Imprint.	18

1 Foreword

These operating instructions have been written for installers and operators and must be kept for future reference. Read these operating instructions carefully and ensure that you have fully understood the contents before installing or working with the probe.

2 Safety

2.1 Notes and symbols used

Warnings for personal injury / damage to property are designed according to the "SAFE" principle. This means that they contain information on the type and source of the hazard, possible consequences and how to avoid and prevent the hazard. The following hazard classifications apply to the safety instructions:

DANGER

Danger indicates a hazardous situation; failure to comply will result in death or serious injury. The symbol in front of the warning indicates the type and source of the danger graphically.

WARNING

Warning indicates a hazardous situation; failure to observe this warning may result in death or serious injury. The symbol in front of the warning indicates the type and source of the danger graphically.

CAUTION

Caution indicates a hazardous situation; failure to observe this warning may result in injury. The symbol in front of the warning indicates the type and source of the danger graphically.

NOTE

Note indicates a situation, non-observance can lead to material damage and impair the function of the product.

TIP

Tip provides additional and useful information on handling the product.

Icon	Meaning
▶	Avoiding and averting the danger in the warning notice
1. 2. ...	Instruction for action All instructions for an action process are always written and listed in chronological order.
▪	List

WARNING



If the sensor is used as a safety component, people can be seriously injured or killed!

- ▶ Do not use the sensor as a safety component.

A laser of laser class 1 DIN EN 60825-1:2015-7 is installed in the CALIS level sensor.



WARNING



Improper work on electrical systems!

Electric shock can cause fatal or life-threatening injuries.

- ▶ Before working on electrical systems, de-energize them and secure them against being switched on again.
- ▶ Work on electrical systems may only be carried out by qualified personnel in accordance with local and national electrical regulations and provisions.

2.2 Personnel qualification

A qualified electrician is a person with suitable technical training, knowledge and experience as well as knowledge of the relevant standards, who can assess the work assigned to them accordingly and recognize potential hazards.

2.3 Intended use

The sensor continuously measures the distance to an object and, depending on its use, calculates the fill level in a container. The sensor is intended for use in accordance with the points and values listed here [in chapter 9, "Technical data"](#).

- Only connect to an overcurrent protection device.
- Only connect to a SELV source in accordance with HD 60364-4-41:2007, 414.3 or comparable.

2.4 Reasonably foreseeable misuse

Any use other than that specified in [chapter 2.3, "Intended use"](#) or use beyond this is considered improper use.

The sensor is not suitable for the following applications:


- Safety component according to Directive 2006/42/EC
- Potentially explosive atmospheres
- Areas with high direct or indirect ambient light exposure
- Railroad sector (rail traffic).

3 General description

The CAS-MQEU-M01-xxxx is a non-contact level sensor that uses optical time-of-flight measurement to measure the distance to the object, which it converts into a level based on calibration points taught in by the operator and makes this available via an analog signal.

Both the measured distance and the level determined according to the calibration are output via the serial IO-Link interface.

In addition, the fill level sensor outputs a switching signal via the digital interface at a defined fill level after appropriate configuration by the operator.



A	Process connection
B	Wrench flat 23
C	Status display <ul style="list-style-type: none"> ▪ LED lights up: Ready for operation <ul style="list-style-type: none"> ▶ green: high fill level ▶ yellow-orange: changes as the fill level drops ▶ red: low fill level ▪ LED flashes: <ul style="list-style-type: none"> ▶ red: fill level < 5 % ▶ orange: Error message
D	M12 connection

4 Installation

NOTE

Incorrect installation can lead to incorrect measurement results or damage to the sensor.

- Observe the minimum distance between the sensor and the side walls.
- Check the mounting surface for evenness and cleanliness.
- During installation, apply a chemical threadlocker to the process connection to suit the operating conditions.

4.1 Determine the minimum distance to the side walls

The infrared, non-visible light beam spreads out with an opening angle and creates a light spot depending on the distance. The diameter of the light spot as a function of the distance to the exit surface of the light beam is listed in the following table. Boundary walls of the tank must not penetrate the light cone along the beam. The maximum necessary distance is required at the minimum fill level and is calculated as follows.

1. Measure the distance between the sensor and the medium at minimum level.
2. Select the corresponding Ø light spot from the table below.
3. The minimum distance to the tank wall = Ø light spot / 2 + 10 mm.

Example: Distance between sensor and medium at minimum level is 400 mm (resulting diameter of the light spot 192 mm).

$$192 \text{ mm} / 2 + 10 \text{ mm} = 106 \text{ mm}$$

Mount the sensor approx. 110 mm from boundary surfaces.

Distance from sensor (mm)	Ø light spot (mm)
60	28,8
80	38,4
100	48,0
120	57,6
140	67,2
160	76,8
180	86,4
200	96,0
300	144,0
400	192,0
500	240,0
600	288,0
800	384,0
1000	480,0
1200	576,0

4.2 Installation implementation

Requirements: Mounting surface is even and clean.

1. De-energize the system and secure it against being switched on again.
2. Screw the sensor into the thread provided in the container.
3. Check that the plug and socket are clean and clean them if necessary.
4. Connect the plug and the socket.
5. Connect the probe electrically according to the terminal assignment.

5 Operation

Continuous measurement begins <1 second after the power supply is switched on. If no valid value is measured within 5 minutes, the sensor restarts.

The analog signal corresponds to a fill level between 0 % (4 mA) and 100 % (20 mA). The fill level is determined from the measured distance according to the configuration used.

The sensor is connected to an IO-Link master and a computer for operation. The following actions are possible:

- Identify sensor
- Read out current process data
- Read out diagnostic data
- Configure sensor

To read out sensor data and change parameters, connect the device to an IO-Link master. For more information on connecting to the IO-Link master, please refer to the documentation for the IO-Link master. Load the device-specific IODD.

The user interface has the following four tabs:

- **Identity:** Information on the manufacturer and product, including IDs.
- **Firmware update:** Option to install new device firmware.
- **Specialist:** Information on current process data, device features and diagnostics as well as carrying out parameterization.
- **Events:** Information on events such as errors and warnings.




Figure 1 - Four tabs of the user interface

5.1 Identity tab

The *Identity* tab lists the basic data on the manufacturer and product, including the pin assignment.




Figure 2 - Identity tab

5.2 Firmware Update tab

If new firmware is required, the software is stored here and saved on the sensor. The firmware is provided by CAPTRON.




Figure 3 - Firmware update tab

5.3 Specialist tab

The sensor is parameterized and calibrated in the *Specialist* tab.

The *Specialist* tab is divided into the following five sub-tabs:

- Process data
- Identification
- Parameters
- Monitoring
- Diagnosis




Figure 4 - Specialist tab

5.4 Process data sub-tab

The measured distance, the calculated fill level and the logical status of the digital output are displayed in the *process data*. ("see Figure 5 - Process Data", field 1).

If the resulting values for the 0 % and 100 % levels are within the measuring range of the probe during calibration, the both negative values and values above 100 % are displayed.




Figure 5 - Process Data

5.5 Identification sub-tab

In addition to the information in [section 5.1, "Identity tab"](#), further information such as details of the hardware and firmware versions are listed, as well as options for assigning tags to the application, function and location ("see Figure 6 - Identification", field 1).




Figure 6 - Identification

5.6 Parameter sub-tab

The *Parameters* sub-tab has several sub-chapters.

TIP

Each changed value must be saved using the "Write" button. If several values have been changed, the "Write all" button can be pressed.

5.7 Configuration of the measurement - distance for overflow warning

Below a distance defined as fill level 100 %, a threshold can be defined that is to be used to signal an overflow (["see Figure 7 - Overflow warning distance"](#), field 1).

If this distance is reached or undershot, the value 2 mA is output at the analog output and the LED flashes 5 times repeatedly.




Figure 7 - Overflow warning distance

5.8 Adjustment of the sensor (fill level to distance) - Container Teach in

Up to 6 calibration points can be used, between which the level is calculated by linear regression as a function of the distance from the sensor. At least 2 adjustment points ("High level" and "Low level") must be used.

- The fill level for each calibration point must be entered manually (["see Figure 8 - Container Teach in"](#), field 1).
- the distance can either be entered manually (["see Figure 8 - Container Teach in"](#), field 2).

Or

- By filling the container to the corresponding fill level and pressing the "Calibrate ... Level" or "Set Additional Reference x" you can the sensor measures the associated distance for the corresponding calibration point. (["see Figure 8 - Container Teach in"](#), field 3)



Figure 8 - Container Teach in

Irrational definitions such as greater distance at higher fill levels are interpreted by the sensor as

error is detected and displayed by the flashing LED. At the same time, this error is listed in the *Event* tab.

The following default values are set at the factory:

- High level 100 % and 40 mm
- Low level 0 % and 1200 mm
- all "additional references" - 1 (not set)

As a result, there is a linear relationship between the distance over the entire measuring range and the current value.

5.9 Pin 4 Configuration

Pins 4 can be configured as switching points. The following table shows which configurations are possible.

PIN	Signal	Description
4	Switching output IO - Link communication	PNP / NPN or push-pull; NO / NC

- Define function with the drop-down list *Pin 4 Function* ("[see Figure 9 - Pin 4 configuration](#)", field 1).
 - ▶ Default value is PNP.
- Define output with the drop-down list *Output Function* ("[see Figure 9 - Pin 4 configuration](#)", field 2).
 - ▶ Default value is NO.
- Enter the switching point as a percentage value in the *Output Set Point* field ("[see Figure 9 - Pin 4 configuration](#)", field 3).
 - ▶ Default value is 50%.
- Enter the reset value of the switching point in the *Output Hysteresis* field as a percentage value ("[see Figure 9 - Pin 4 configuration](#)", field 4).
 - ▶ Default value is 10%.
- Enter the minimum length of the output pulse in the *Output Minimum Impulse Time* field.

Default value is 300 ms ("[see Figure 9 - Pin 4 configuration](#)", field 5)
- Confirm all entered values with *Write*.




Figure 9 - Pin 4 configuration

If an output is to be closed when the level falls below a defined level, then define the output as "normally closed" and set the defined level at set point minus hysteresis and the set point is then above the defined level, quasi as a hysteresis level above the switching point.

5.10 Brightness of the LED

- The brightness can be set by entering a percentage value from 1 to 100 % ("see [Figure 10 - Observation and Diagnosis](#)", field 1).
 - The default value is 25 %.




Figure 10 - Observation and diagnosis

5.11 Observation sub-tab

The current supply voltage level and the current temperature of the electronics in the sensor are displayed in this area ("see [Figure 10 - Observation and diagnosis](#)", field 2).

5.12 Diagnosis sub-tab

A reset can be performed on the sensor in this area ("see [Figure 10 - Observation and Diagnosis](#)", field 3). Four types of resets are possible in accordance with the IO-Link standard.

Name	Description
Reset device	A warm start is triggered and the device is reset to its initial state. Communication is interrupted by the device and then restarted by the master.
Reset application	The parameters of the technology-specific application are set to default values. The identification parameter remains unchanged. An upload to the data memory of the master is carried out if this is activated in the port configuration of the master.
Restore factory settings	The device parameters are reset to the factory settings. Note: Downloading the data storage can overwrite the factory settings the next time the device is switched off and on again.
Back-to-Box	The device parameters are reset to the factory settings and communication is blocked until the next time the device is switched off and on again. Note: Disconnect the device directly from the master connection.

The status of the sensor (device status) is shown in accordance with the specifications of the IO-Link standard.

The error code is only displayed temporarily as long as the error exists. The illustration shows that the container is overfilled. The following error codes are available.

Blink Code	I0-Link error code	Description
1	0x0001	Internal error
2	0x0002	Error of an internal voltage
4	0x0008	Supply voltage too high / low
5	0x0010	Container overfilled / sensor error
8	0x0080	Parameter memory error
9	0x0100	Parameter error
12	0x0800	LED error
13	0x1000	Load on digital output too high
15	0x4000	Temperature too high

5.13 Events tab

The *Event* tab provides a log book. The following events can be recorded.

Event no.	Type	Definition and recommended action
16912	Warning	Overheating of the appliance - remove the heat source
20496	Error	Hardware malfunction - device replacement
20752	Warning	Supply voltage too high - Check supply voltage
20753	Warning	Supply voltage too low - Check supply voltage
25376	Error	Parameter error - check set values according to data sheet

6 Maintenance

Clean the front screens of the sensor regularly depending on how dirty they are used.

7 Dismantling

1. De-energize the system and secure it against being switched on again.
2. Disconnect the electrical connection and remove the sensor.

8 Waste disposal

Electrical and electronic components of various types must be sorted for recycling. All applicable state, federal and local laws and regulations must be complied with without restriction.

9 Technical data

Operating voltage	DC 24 V (16.8...30.0 V) for max. 0.1 s 14.4 V, for max. 1.0 s 33.6 V
Process connection	V4A
Operating temperature	-40 °C (-40 °F)...+70 °C (158 °F)
Storage temperature	-40 °C (-40 °F)...+70 °C (158 °F)
Protection class IP	IP67
Analog interface	4 ... 20 mA (0 % ... 100 % fill level) 2mA for warning threshold and error
Digital output	PNP, NPN, PushPull; NO/NC
Communication interface	IO-Link version 1.1
Measuring principle	ToF
Laser class (IEC 60825-1:2015-7)	940 nm Class 1
Measuring range	40 mm -1200 mm
Accuracy	+/- 20 mm at 20 °C
Standby time	<1 s
Response time	2,2 s
Operating current (IB)	85.1 mA at 24 V and 50 mA load current at the switching output
Maximum output load Current output	250 Ω
Inrush current	Typically 8.55 A at 24 V
Melting integral	Typically 123.97 A ² μs at 24 V
MTBF	>780,00h at 40°C; >144,000h at 70°C

9.1 Dimensioned drawing





Figure 11 - Dimensional drawing

9.2 Pin assignment

M12 plug, 5-pin



Pin	Signal	Description
1	U _v	Operating voltage
2	Analog fill level signal	4...20 mA (0 % ... 100 % fill level); 2 mA for warning threshold or error
3	GND	0 V
4	Digital output IO-link communication	PNP, NPN, PushPull; NO/NC
5	n.c.	-

10 Manual updates

CAPTRON reserves the right to adapt the content of these instructions if necessary. The latest version can be found on our website www.captron.com.

11 Legal notice

The information contained in this document on sensors, sensor probes, devices, applications and software is for information purposes only and may be superseded by updates at any time. It is your responsibility to ensure that your applications comply with your specifications.

CAPTRON makes no representations or warranties, express or implied, with respect to the information, including, but not limited to, its content, condition, quality and fitness for a particular purpose. CAPTRON disclaims all liability arising from this information and its use.

The use of CAPTRON sensors, sensor buttons, devices, applications and software in life-sustaining and/or safety-related applications is solely at the risk of the user.

Buyer agrees to defend, indemnify and hold CAPTRON harmless from any damages, claims, actions or costs resulting from such use. Unless otherwise specified, no licenses to CAPTRON's intellectual property rights are conveyed, by implication or otherwise.

Trademark

The CAPTRON name and logo, CANEO and oneGRID are registered trademarks of CAPTRON in various countries and are the property of CAPTRON Electronic GmbH.

All other trademarks mentioned herein are the property of their respective owners.

© 2024, CAPTRON Electronic GmbH, All rights reserved.

12 Imprint

The operating instructions were written and published by

CAPTRON Electronic GmbH

Johann-G.-Gutenberg-Straße 7

82140 Olching - Germany Phone:

+49 (0)8142 - 44 88 - 160

sales@captron.com

www.captron.com

Copyright 2022

CALIS-MQEU-M01- _____ersion 1.1